




Cap service centre

Version: 12-2008

Automatic cap change and milling centre

- Disengaging the caps
- Attaching new caps (Ø 13, 16, 20 mm)
- Sensory caps-check
- Milling or remilling
- Monitoring the magazine level
- Check before and after cap changing
- Cuts out automatically if collisions or faults occur



WMA is general distributor for NIMAK welding machines in Baden-Wuerttemberg

We reserve the right to make changes which are in the interest of technical progress.

© by WMA Schmidt & Bittner GmbH, Baumwaide 23, D-74360 Illfeld-Auenstein, Tel. +49 7062 9066-0, Fax +49 7062 9066-20
info@wma-sb.de or wma-sb@t-online.de, <http://www.wma-sb.de>

Cap-Service-Center-1